


Best.-Nr.: 2030048572
PWC3O0002



DE
EN
IT

EN

3

Please refer to the graphics in the German Installation and Operating Instructions.

IT

13

Per le grafiche fare riferimento alle Istruzioni per il montaggio e l'uso in tedesco.

Tap Components for Washbasin Unit for Contact-Free Water/Hot Air Sequential Control.

Please refer to the graphics in the German Installation and Operating Instructions.

Table of Contents

1. Abbreviations and units	4
2. Key	4
3. Warranty	4
4. Important notes	4
Description of product	
5. Application	5
6. Technical specifications	5
7. ID settings (29260)	6
8. Dimensions	6
9. Installation example	6
Assembly, function and commissioning	
10. Assembly	7
11. Assembly of hand dryer	9
12. Startup	10
13. Function	10
14. Setting the sensor	10
Maintenance	
15. Maintenance and care	11
16. Replacing the filters	11
17. Troubleshooting	11
18. Spare parts	12

1. Abbreviations and units

DN	Nominal diameter in mm
RCD	Residual current protective device, Earth leakage circuit breaker
SELV	Safety extra low voltage
EA-Nr.	European article number
Best.-Nr.	Aquarotter order number
Conversion	1 mm = 0.03937 inches 1 inch = 25.4 mm

All length specifications in the graphics are in mm.

2. Key

Warning!

Failure to observe can result in bodily injury or even death.

Caution!

Failure to observe can result in material damage.

Important!

Failure to observe can cause the product to malfunction.

Useful information for optimum handling of the product.

3. Warranty

Liability is accepted in accordance with the General Terms and Conditions of Business and Supply.

Use only genuine spare parts!

4. Important notes

- Installation, commissioning and maintenance must be performed only by a qualified expert in accordance with the instructions provided, legal requirements and recognised engineering standards.
- All technical connection regulations specified by the local water and electricity supply companies must be observed.
- The power supply should be switched off before any work is carried out.
- We reserve the right to make changes.

5. Application

A3000 open, electronically controlled washbasin tap, DN 15, with concealed trigger via pictograph tile, for washing hands and sequential control for drying hands for wall-mounted washbasin, with possibility of external control, such as tap adjustment and communication using ECC function controller. For connection to premixed hot water or cold water. The flow time can be set in one-second steps.

Control functions:

- Optional temperature sensor with temperature measurement and log saving every 60 seconds, every 10 seconds for thermal disinfection
- Time-controlled hygiene flushes, optionally at fixed intervals or at a defined interval after last operation

Additional functions with ECC function controller (Ethernet):

- Automatic thermal disinfection in accordance with DVGW Work Sheet W 551 and safety shutdown
- Cleaning deactivation

6. Technical specifications

Minimum flow pressure:	1.0 bar
Recommended flow pressure:	1-5 bar
Maximum operating pressure:	10 bar
Calculated flow rate:	0.20 l/s
Volumetric flow:	0.50 l/s at a flow pressure of 3 bar
Washbasin components	24 V DC
Hand dryer	230 V AC
Power consumption:	
Washbasin components	7 W
Hand dryer	1770 W
Communication:	Ethernet via ECC function controller
Protection class:	
Electronic module	IP 68
Solenoid valve	IP 44

7. ID settings (29260)

Water-air combi/capacitive sensor/hand dryer sequential control.

FUNCTION:

Start of water flow at touch of button, automatic stop after end of set flow time in 10 s. Then hand dryer starts. Automatic stop after end of set flow time in 20 s.

SENSORS:

S2: Channel 1/capacitive sensor

ACTUATORS:

A1.1: Channel 1/power switch/hand dryer

A1.2: Channel 1/solenoid valve

SETTINGS:

Range	- / - / -
TempSensor 1 action	-
TempSensor 2 action	-
AquaPay	-
Flow Time	10 sec. / - / -
Overrun time	- / - / -
Safety shutdown after	-
Reflection alarm after	-
Concurrence suppression	-
Flow time reduction	-
Cleaning deactivation	1 min.
Hygiene flush (dynamic)	Interval: 24 h/flow time: 10 sec.
Hygiene flush (fixed)	Interval: 0 h/flow time: 10 sec.
Power-on flush	-
TD Application Time	-
TD water saving function	-
TD cooling	-

8. Dimensions

9. Installation example

10. Assembly

⚠ Warning!

- Place the power supply (not part of the delivery, see [Chapter 18.](#), accessories) outside the wet area in a separate room.
- Operate the product only with safety extra low voltage (SELV). The components must not be earthed.
- Protect the power supply with a residual current circuit breaker (RCD).

Failure to observe this instruction can result in death or material damage due to electric shock or fire, for example.

- ☞ Lay the system line (not part of the delivery, see [Chapter 18.](#), accessories) in an empty pipe (to be provided by the customer) from the power supply to the taps and loop through.

⚠ Warning!

Only operate taps with the designated filter.

Failure to observe this instruction can result in damage to the tap.

10.1 Important!

Prior to the assembly process, flush the pipework in accordance with DIN 1988.

10.2 Establish the water connection.

- ☞ Take note of the flow direction.

10.3 Use an Allen key to close the water volume regulator.

a: Closed

b: Open

10.4 Unscrew the locking screw (c) on the water volume regulator.

10.5 Replace the (d) filter.

- ☞ Important!

Note the installation position of the filter.

10.6 Remove the flush connector.

10.7 Attach the connection cable.

10.8 Insert the solenoid valve with the seals.

- ☞ Take note of the flow direction.

10.9 Open the water volume regulator (see [Work step 10.3](#)).

10.10 Affix the sensor (e) to the rear of the plastic tile (f).

- ☞ No tile cement may be applied between the sensor and the plastic tile.

Installing the electrical T-distributor

Important!

The components of the electrical T-distributor may only be installed after the power has been switched off.

Recommended system cable see [Chapter 18.](#), accessories.

When using cables other than the system cable, pay attention to the different colour code. The outer diameter must not exceed 7.5 mm.

10.11 Remove the sheathing (a) of the system cable (approx. 40 mm).

10.12 Push the cap nut (c) onto the system cable (b) up to the stop.

The various wire guides are marked with numbers 1 to 4.

A: Union nut

B: Best.-Nr. 2000104272

Best.-Nr. 2000104274

Best.-Nr. 2000100801

Best.-Nr. 2000100852

	A	B
1	brown	red
2	white	white
3	blue	blue
4	black	black

10.13 Push the wires (d) into the wire guides (e) in accordance with their colours.

10.14 Cut off the projecting wire ends flush, i.e. without protrusions.

10.15 Push the cap nut (c) onto the electrical T-distributor (f) and tighten with the required torque (1.2 Nm).

Caution!

Note the polarity.

The same wire colour must be in the same wire guide for both union nuts.

When tightening the union nut, the electrical contact and tension relief are created automatically.

Special seals act as protection from dust and water.

10.16 Connect the cables between the electronics module, power switch, and sensor.

- A: Power switch (actuator 1)
- B: Actuator 2 (optional)
- C: 0-10 V analogue output
- D: Cold water temperature sensor (optional)
- E: Hot-water temperature sensor (optional)
- F: Capacitive sensor (sensor connection 2/3)
- G: Not used (sensor connection 1)
- H: Electrical T distributor system cable (power)
- K: Electronic module

10.17 Connect the cables between the electronics module, solenoid valve, and hand dryer.

- F: Electronics module (actuator 1)
- G: Solenoid valve
- H: Switch contact for hand dryer

11. Assembly of hand dryer

11.1 Attach the mounting template to the wall. The recommended mounting height is between 130 and 140 cm above the floor.

11.2 Drill the mounting template accordingly (A, B, C, D).

11.3 Remove the mounting template from the wall. Insert the wall plugs.

11.4 Turn out the two screws (a) on the housing.

11.5 Remove the hand dryer housing.

11.6 Guide the electrical cable and the cable of the power switch through the base plate.

11.7 Mount the base plate and motor to the wall.

- 1 Screw
- 2 Washer
- 3 Spacer
- 4 Base plate
- 5 Washer
- 6 Nut

11.8 Connect the electrical cable (a).

- L: Red (or brown)
- N: Black (or blue)
- \ominus : Green (or yellow)

11.9 Connect the cable of the power switch (b).

11.10 Screw the housing (c) to the base plate.

11.11 Shorten the hose (d).

Important!

Do not (d) bend the hose.

11.12 Attach the hose max. 20 mm in the hand dryer outlet.

11.13 Attach the hose to the hand dryer outlet using the screws.

11.14 Push the pipe clamp onto the hose.

11.15 Attach the hose to the washbasin nozzle with the pipe clamp.

12. Startup

12.1 Turn the power on.

12.2 Allow the system to run in for at least 15 min.

12.3 Stroke over the plastic tile with your hand.

- The water will flow.

13. Function

13.1 Stroke over the plastic tile with your hand.

- The water will flow.
- The water flow stops automatically after the set flow time (10 seconds).
The hand dryer then activates for 20 seconds.

 An automatic flushing function after 24 hours of non-use was set in the factory.

 You can set the flow time and automatic flush using the system software.

14. Setting the sensor

14.1 Use a screwdriver to set the range.

- + Longer range
- Shorter range

15. Maintenance and care

The tap must be checked and maintained at regular intervals in accordance with the water quality and the local conditions and rules and regulations applicable at the site (DIN EN 806-5).

Maintain the following components:

- Aerator (see instructions for outlet)
- Filters (see [Chapter 16.](#))

Use suitable cleaning agents which do not attack the tap in a proper manner and rinse with water after use. High-pressure cleaners must not be used for cleaning.

16. Replacing the filters

Water volume regulator filter

- 16.1 Close the water volume regulator (see [Work step 10.3](#)).
- 16.2 Unscrew the locking screws (a) on the water volume regulators.
- 16.3 Replace the filters (b).
- 16.4 Reassemble in reverse order.

17. Troubleshooting

Fault	Cause	Remedy
Water does not flow	<ul style="list-style-type: none">– Shut-off valve closed– Power supply interrupted– Water supply interrupted– Electronics module faulty– Sensor faulty– Solenoid valve faulty	<ul style="list-style-type: none">⇒ Open it⇒ Restore it⇒ Restore it⇒ Replace it⇒ Replace it⇒ Replace it
Water flows continuously	<ul style="list-style-type: none">– Dirty solenoid valve– Solenoid valve faulty	<ul style="list-style-type: none">⇒ Clean it⇒ Replace it
Water volume too low	<ul style="list-style-type: none">– Supply pressure too low– Dirty filter– Water volume regulator not fully open– Shower head blocked with scale	<ul style="list-style-type: none">⇒ Check it⇒ Clean it⇒ Open it⇒ Clean it

If you cannot rectify a fault or if it is not in the list, please contact our customer service department!

18. Spare parts

Description	Order No.	Accessories	Order No.
7 Hand dryer	2000109021	ECC2 function controller (60 W) with Ethernet connection	
8 Capacitive sensor	2030040076	ECC-2	2000108123
9 Power switch	2030004170	Power pack (12 W)	2000100375
10 Electronics module M1	2030057722	Power pack (60 W)	2030068573
11 24 V DC solenoid valve	2000104454	System cable for continuous use in water, halogen-free 100 m	2000104272
12 Filter (packaging unit10x)	2000104749	halogen-free 25 m	2000104274
Mounting kit consisting of:		System cable, not halogen-free 100 m	2000100801
Filter		not halogen-free 25 m	2000100852
O-ring			
Seals	2000104872		

Componenti di apparecchiatura da gruppo lavabo per comando successivo senza contatto acqua / aria calda.

Si prega di consultare le illustrazioni contenute nella versione tedesca delle Istruzioni di installazione e di esercizio.

Indice

1.	Abbreviazioni e unità	14
2.	Spiegazione dei simboli	14
3.	Garanzia	14
4.	Indicazioni importanti	14

Descrizione del prodotto

5.	Impiego	15
6.	Dati tecnici	15
7.	ID impostazioni (29260)	16
8.	Misure	16
9.	Esempio di installazione	16

Montaggio, funzionamento e messa in servizio

10.	Montaggio	17
11.	Montaggio asciugamani	19
12.	Messa in servizio	20
13.	Funzionamento	20
14.	Impostazioni sensore	20

Manutenzione

15.	Manutenzione e cura	21
16.	Sostituzione dei filtri	21
17.	Eliminazione delle anomalie	22
18.	Ricambi	22

1. Abbreviazioni e unità

DN	Diametro nominale in mm
RCD	Residual Current Protective Device, interruttore differenziale
SELV	Safety Extra Low Voltage, bassissima tensione di sicurezza
EA-Nr.	Codice articolo europeo
Best.-Nr.	Codice ordinazione Aquarotter
Conversione	1 mm = 0,03937 pollici 1 pollice = 25,4 mm

Tutte le indicazioni di lunghezza nelle figure sono in mm.

2. Spiegazione dei simboli

Avvertenza!

La mancata osservanza può comportare pericolo di morte o lesioni.

Attenzione!

La mancata osservanza può comportare danni materiali.

Importante!

La mancata osservanza può comportare anomalie nel funzionamento del prodotto.

 Informazioni utili per l'uso ottimale del prodotto.

3. Garanzia

La responsabilità viene assunta in conformità alle condizioni generali di vendita e fornitura.

Utilizzare solo ricambi originali!

4. Indicazioni importanti

- Per il montaggio, la messa in servizio e la manutenzione incaricare solo un tecnico specializzato, nel rispetto delle istruzioni fornite, delle norme di legge e delle norme tecniche riconosciute.
- Attenersi alle disposizioni tecniche di allacciamento degli enti erogatori di acqua ed energia locali.
- Eseguire tutti i lavori in assenza di tensione.
- Con riserva di modifiche.

5. Impiego

A3000 open, apparecchio da zona lavabo a comando elettronico DN 15, con attivazione invisibile mediante piastrella con pittogramma, per lavarsi le mani e con comando successivo per asciugarsi le mani, per lavello da incasso a parete, con possibilità di comando esterno, come regolazione apparecchio e comunicazione tramite controller ECC. Da collegare ad acqua calda o fredda pre-miscelata. Durata del flusso regolabile al secondo.

Funzioni di comando:

- Sensore di temperatura opzionale con misurazione della temperatura e salvataggio del registro ogni 60 secondi, in caso di disinfezione termica ogni 10 secondi
- Lavaggi igienici temporizzati, a scelta con intervallo fisso o dopo un tempo definito dall'ultimo azionamento

Funzioni aggiuntive con controller ECC (Ethernet):

- Disinfezione termica automatica secondo foglio di lavoro DVGW W 551 e spegnimento di sicurezza
- Spegnimento per pulizia

6. Dati tecnici

Pressione minima del flusso:	1,0 bar
Pressione del flusso raccomandata:	1–5 bar
Pressione d'esercizio massima:	10 bar
Portata nominale:	0,20 l/s
Portata in volume:	0,50 l/s con pressione del flusso di 3 bar
Componenti della zona lavabo	24 V CC
Asciugamani	230 V CA
Potenza assorbita:	
Componenti della zona lavabo	7 W
Asciugamani	1770 W
Comunicazione:	Ethernet mediante controller ECC
Tipo di protezione:	
Modulo elettronico	IP 68
Valvola elettromagnetica	IP 44

7. ID impostazioni (29260)

Sensore capacitivo combinato acqua / aria / comando successivo per asciugamani

FUNZIONE:

Avvio del flusso d'acqua con pressione del tasto, arresto automatico in 10 s. allo scadere della durata del flusso impostata. Poi si avvia l'asciugamani.

Arresto automatico in 20 s. allo scadere della durata del flusso impostata.

SENSORI:

S2: canale 1 / sensore capacitivo

ATTUATORI:

A1.1: canale 1 / interruttore di potenza / asciugamani

A1.2: canale 1 / valvola elettromagnetica

IMPOSTAZIONI:

Portata	- / - / -
TempSensor 1 azione	-
TempSensor 2 azione	-
Aquapay	-
Durata del flusso	10 sec. / - / -
Durata di arresto del flusso	- / - / -
Spegnimento di sicurezza dopo	-
Allarme riflessione	-
Soppressione della contemporaneità	-
Riduzione della durata del flusso	-
Spegnimento per pulizia	1 min.
Risciacquo igienico (dinamico)	Intervallo: 24 ore / durata del flusso: 10 sec.
Risciacquo igienico (fisso)	Intervallo: 0 ore / durata del flusso: 10 sec.
Risciacquo accensione	-
Tempo di azione TD	-
Funzione di risparmio TD	-
Raffreddamento TD	-

8. Misure

9. Esempio di installazione

10. Montaggio

⚠ Avvertenza!

- Collocare il sistema di alimentazione della tensione (non compreso nella fornitura, vedere [capitolo 18.](#), Accessori) al di fuori della zona umida in un locale separato.
- Far funzionare il prodotto solo con una bassissima tensione di sicurezza (SELV). Non collegare a massa i componenti.
- Proteggere il collegamento elettrico con un interruttore differenziale (RCD).

La mancata osservanza può comportare pericolo di morte o danni materiali, ad es. a causa di scossa elettrica o incendio.

☞ Posare il cavo di sistema (non compreso nella fornitura, vedere [capitolo 18.](#), Accessori) nel tubo canalina (da approntare in loco) dall'alimentazione di tensione agli apparecchi ed eseguire una connessione passante.

⚠ Avvertenza!

Utilizzare l'apparecchio solo con il filtro previsto.

La mancata osservanza può causare danni all'apparecchio.

10.1 Importante!

Prima del montaggio sciacquare le tubazioni secondo la norma DIN 1988.

10.2 Realizzare l'allacciamento idrico.

☞ Prestare attenzione alla direzione del flusso.

10.3 Chiudere il regolatore della quantità d'acqua con una brugola.

a: chiuso

b: aperto

10.4 Avvitare il tappo a vite (c) del regolatore della quantità d'acqua.

10.5 Sostituire il filtro (d).

☞ Importante!

Prestare attenzione alla posizione di montaggio del filtro.

10.6 Smontare il connettore di lavaggio.

10.7 Applicare il cavo di collegamento.

10.8 Inserire la valvola elettromagnetica con le guarnizioni.

☞ Prestare attenzione alla direzione del flusso.

10.9 Aprire il regolatore della quantità d'acqua (vedere [fase di lavoro 10.3](#)).

10.10 Incollare il sensore (e) al lato posteriore della piastrella di plastica (f).

☞ Non applicare colla per piastrelle tra il sensore e la piastrella di plastica.

Montaggio del distributore elettrico a T

☞ Importante!

I componenti del distributore elettrico a T vanno montati solo in assenza di tensione.

☞ Cavo di sistema raccomandato vedere [capitolo 18.](#), accessori.

Se come cavo di sistema si usano altri cavi, prestare attenzione ad eventuali cambiamenti del codice cromatico. Il diametro esterno non deve superare i 7,5 mm.

10.11 Rimuovere il rivestimento (a) del cavo di sistema (circa 40 mm).

10.12 Applicare i dadi di raccordo (c) al cavo di sistema (b) fino alla battuta.

☞ Le guide dei conduttori sono contrassegnate con i numeri da 1 a 4.

A: dadi di raccordo

B: Best.-Nr. 2000104272

Best.-Nr. 2000104274

Best.-Nr. 2000100801

Best.-Nr. 2000100852

	A	B
1	marrone	rosso
2	bianco	bianco
3	blu	blu
4	nero	nero

10.13 Innestare i conduttori (d) nelle rispettive guide (e) in base al colore.

10.14 Tagliare le sporgenze dei conduttori a raso, ossia senza prominenza.

10.15 Collocare i dadi di raccordo (c) sul distributore elettrico a T (f) e stringerli alla coppia richiesta (1,2 Nm).

⚠ Attenzione!

Prestare attenzione alla polarità.

Ogni conduttore di un determinato colore deve trovarsi nella stessa guida nei due dadi di raccordo.

☞ Quando si serrano i dadi di raccordo, il contatto elettrico e lo scarico della trazione vengono stabiliti automaticamente.

Proteggere le guarnizioni speciali da polvere e acqua.

10.16 Stabilire i collegamenti via cavo tra il modulo elettronico, l'interruttore di potenza e il sensore.

- A: interruttore di potenza (attuatore 1)
- B: attuatore 2 (opzionale)
- C: uscita analogica 0-10 V
- D: sensore di temperatura acqua fredda (opzionale)
- E: sensore di temperatura acqua calda (opzionale)
- F: sensore capacitivo (attacco sensore 2/3)
- G: non occupato (attacco sensore 1)
- H: distributore elettrico a T cavo di sistema (power)
- K: modulo elettronico

10.17 Stabilire i collegamenti via cavo tra il modulo elettronico, la valvola elettromagnetica e l'asciugamani.

- F: modulo elettronico (attuatore 1)
- G: valvola elettromagnetica
- H: contatto di commutazione per asciugamani

11. Montaggio asciugamani

11.1 Fissare la sagoma di montaggio alla parete. L'altezza di montaggio consigliata è compresa tra 130 e 140 cm di distanza dal pavimento.

11.2 Praticare fori corrispondenti alla sagoma di montaggio (A,B,C,D).

11.3 Togliere la sagoma di montaggio dalla parete. Inserire i tasselli.

11.4 Svitare le due viti (a) dell'alloggiamento.

11.5 Togliere l'alloggiamento dell'asciugamani.

11.6 Introdurre il cavo elettrico e il cavo dell'interruttore di potenza attraverso la piastra di base.

11.7 Montare la piastra di base con motore sulla parete.

- 1 Vite
- 2 Rondella
- 3 Distanziale
- 4 Piastra di base
- 5 Rondella
- 6 Dado

11.8 Collegare il cavo elettrico (a).

- L: rosso (o marrone)
- N: nero (o blu)
- verde (o giallo)

11.9 Collegare il cavo dell'interruttore di potenza (b).

11.10 Avvitare l'alloggiamento (c) alla piastra di base.

11.11 Accorciare il flessibile (d).

Importante!

Non piegare il flessibile (d)!

11.12 Fissare il flessibile nell'erogatore dell'asciugamani per massimo 20 mm.

11.13 Con le viti, fissare il flessibile all'erogatore dell'asciugamani.

11.14 Spingere la staffa per tubi sul flessibile.

11.15 Con la staffa per tubi, fissare il flessibile al bocchettone del lavello.

12. Messa in servizio

12.1 Inserire la tensione.

12.2 Lasciare avviare l'impianto per almeno 15 min.

12.3 Passare la mano sulla piastrella di plastica.

- L'acqua scorre.

13. Funzionamento

13.1 Passare la mano sulla piastrella di plastica.

- L'acqua scorre.
- Il flusso d'acqua si arresta automaticamente allo scadere della durata del flusso impostata (10 secondi).
Poi subentra automaticamente la funzione di asciugamani per la durata di 20 secondi.

 In fabbrica è impostato un lavaggio forzato dopo 24 ore di assenza d'uso.

 La durata del flusso e il lavaggio forzato possono essere impostati mediante il software del sistema.

14. Impostazioni sensore

14.1 Regolare la portata con un cacciavite.

- + portata maggiore
- portata minore

15. Manutenzione e cura

Controllare e sottoporre a manutenzione (DIN EN 806-5) l'apparecchio ad intervalli regolari, in funzione della qualità dell'acqua, delle caratteristiche locali e delle vigenti disposizioni locali.

Sottoporre a manutenzione i seguenti componenti:

- Rompigetto (vedere istruzioni erogatore)
- Filtri (vedere [capitolo 16.](#))

Utilizzare in modo adeguato detergenti adatti che non aggrediscano l'apparecchio e, dopo averli usati, sciacquare con acqua. Non usare idropulitrici per la pulizia.

16. Sostituzione dei filtri

Filtro del regolatore della quantità d'acqua

16.1 Chiudere il regolatore della quantità d'acqua (vedere [fase di lavoro 10.3](#))

16.2 Svitare i tappi a vite (a) dei regolatori della quantità d'acqua.

16.3 Sostituire i filtri (b).

 **Importante!**

Prestare attenzione alla posizione di montaggio dei filtri.

16.4 Il montaggio avviene in sequenza inversa.

17. Eliminazione delle anomalie

Anomalia	Causa	Rimedio
L'acqua non scorre	<ul style="list-style-type: none"> – Rubinetto d'intercettazione chiuso – Alimentazione di tensione interrotta – Alimentazione d'acqua interrotta – Modulo elettronico guasto – Sensore guasto – Valvola elettromagnetica guasta 	<ul style="list-style-type: none"> ⇒ Aprire ⇒ Ristabilire ⇒ Ristabilire ⇒ Sostituire ⇒ Sostituire ⇒ Sostituire
L'acqua scorre ininterrottamente	<ul style="list-style-type: none"> – Valvola elettromagnetica sporca – Valvola elettromagnetica guasta 	<ul style="list-style-type: none"> ⇒ Pulire ⇒ Sostituire
Quantità d'acqua insufficiente	<ul style="list-style-type: none"> – Pressione di alimentazione troppo bassa – Filtro sporco – Regolatore della quantità d'acqua non aperto completamente – Docetta incrostata di calcare 	<ul style="list-style-type: none"> ⇒ Controllare ⇒ Pulire ⇒ Aprire ⇒ Pulire

Qualora non fosse possibile eliminare un'anomalia o se l'anomalia non è riportata nell'elenco, rivolgersi al nostro servizio di assistenza clienti!

18. Ricambi

Denominazione	Cod. Art.	Accessori	Cod. Art.
7 Asciugamani	2000109021	Controller ECC (60 W)	
8 Sensore capacitivo	2030040076	con collegamento Ethernet	
9 Interruttore di potenza	2030004170	ECC-2	2000108123
10 Modulo elettronico M1	2030057722	Alimentatore (12 W)	2000100375
11 Valvola elettromagnetica 24 V CC	2000104454	Alimentatore (60 W)	2030068573
12 Filtro (serie di 10 pezzi)	2000104749	Cavo di sistema per l'impiego continuo in acqua, privo di alogeni 100 m	2000104272
Set di montaggio costituito da:		privo di alogeni 25 m	2000104274
Filtro		Cavo di sistema,	
O-ring		non privo di alogeni 100 m	2000100801
Guarnizioni	2000104872	non privo di alogeni 25 m	2000100852

Notes / Annotazioni

Australia

PR Kitchen and
Water Systems Pty Ltd
Dandenong South VIC 3175
Phone +61 3 9700 9100

Austria

KWC Austria GmbH
6971 Hard, Austria
Phone +43 5574 6735 0

**Belgium, Netherlands &
Luxembourg**

KWC Aquarotter GmbH
9320 Aalst; Belgium
Phone NL +31 (0) 492 728 224
BE/LU +32 (0) 53 60 31 50

Czech Republic

KWC Aquarotter GmbH
14974 Ludwigsfelde, Germany
Phone +49 3378 818 309

France

KWC Austria GmbH
6971 Hard, Austria
Phone +33 800 909 216

Germany

KWC Aquarotter GmbH
14974 Ludwigsfelde
Phone +49 3378 818 0

Italy

KWC Austria GmbH
6971 Hard, Austria
Numero Verde +39 800 789 233

Middle East

KWC ME LLC Ras Al Khaimah,
United Arab Emirates
Phone +971 7 2034 700

Poland

KWC Aquarotter GmbH
14974 Ludwigsfelde, Germany
Phone +48 58 35 19 700

Spain

KWC Austria GmbH
6971 Hard, Austria
Phone +43 5574 6735 211

Switzerland & Liechtenstein

KWC Group AG
5726 Unterkulm, Switzerland
Phone +41 62 768 69 00

Turkey

KWC ME LLC Ras Al Khaimah,
United Arab Emirates
Phone +971 7 2034 700

United Kingdom

KWC DVS Ltd - Northern Office
Barlborough S43 4PZ
Phone +44 1246 450 255

KWC DVS Ltd - Southern Office
Paignton TQ4 7TW
Phone +44 1803 529 021

EAST EUROPE

Bosnia Herzegovina
Bulgaria | Croatia
Hungary | Latvia
Lithuania | Romania
Russia | Serbia | Slovakia
Slovenia | Ukraine

KWC Aquarotter GmbH
14974 Ludwigsfelde, Germany
Phone +49 3378 818 261

SCANDINAVIA & ESTONIA

Finland | Sweden | Norway
Denmark | Estonia

KWC Nordics Oy
76850 Naarajarvi, Finland
Phone +358 15 34 111

OTHER COUNTRIES

KWC Austria GmbH
6971 Hard, Austria
Phone +43 5574 6735 0

